





MICHIGAN PNEUMATIC TOOL, INC.

MP-18400 Portable Band Saw



6850 Middlebelt Rd. • Romulus, MI 48174 • 1-800-521-8104 • Ph: (313) 933-5890 • Fax: (313) 933-0440

www.michiganpneumatic.com • e-mail: mpt@michiganpneumatic.com

03092021Rev1PFT | MF



MICHIGAN PNEUMATIC TOOL, INC.

MP-18400 Portable Band Saw

Index	Part No.	Description	Qty.
1	18409	Stud	4
2	18480	Cover	1
3	18479	Blade	1
4&5	18469	Screw & Washer (Pulley)	2
6/9/10/11	18464	Spring Plate Assembly	1
7	18463	Screw (M5x15)	4
8	18462	Collar	4
12	18459	Left Guide	1
13	18458	Frame	1
15	18484	Bushing	1
17	18454	Tension Handle	1
18	18485	Pan-head Screw	1
19	18456	Grip Handle	1
20	18457	S.H.S.C.	2
21	18478	Guide Bar	1
22	18477	Guide Bar Fasteners	2
23	18453	Gear Shaft	1
24	18412	Helical Gear	1
25	18451	Ball Bearing	1
26	18450	Stop Ring	1
27	18511	Bushing	1
28	18489	Ball Bearing	2
29	18421	Screw	1
30	18420	Washer	1
31	18422	Throttle Adaptor Assy.	1
32	18416	O-ring	1
33	18415	O-ring	1
34	18423	Motor Housing Assy	1
35	18078	O-ring	1
36	18071	Ball Bearing	1
41	18061	Lock Nut	1
42	18414	O-Ring	1
43	18411	Motor Adapter	1
44	18424	Lock Washer	4
45	18725	S.H.C.S.	4
46	17990	Air Motor Cover	1
47	18062	Lock Washer	1

Index	Part No.	Description	Qty.
48	19005	Pinion	1
49	18066	Rotor	1
50	18067	Cylinder	1
51	18069	Rear Plate	1
52	18072	Screw	1
61/62	18468	Pulley Assy.	2
63	18486	Pulley Stud	1
64	18474	Bearing	3
65	18470	Right Guide	1
66	18475	Pin Shaft	1
67	18473	Blade Guide Fasteners	3
68	18488	Bearing Assembly	4
69	18476	Screw	4
70	18482	Square	1
71	18483	Hex Key	1
72	18419	Adjusting Shim	3
73	18077	O-ring	1
74	18321	Bead Chain	1
75	18320	End Coupling	2
76	18319	Drive Stud	2
77	18317	Throttle Screw	1
78	18318	O-ring	1
79	18308	Valve cover	1
80	18309	O-ring	1
81	18310	Spring	1
82	18311	Seal Cup	1
83	18312	Valve Seal	1
84	18313	Valve Pin	1
85	18087	Nut and Screen Assy.	1
86	18314	Throttle Body	1
87	18306	D-Ring	1
88	18336	Trigger Assy (lockout)	1
89	18316	Rivet	1